![DTEN logo]

D7 55"
Product Guide

Packing List

1. DTEN D7 55" (Standard) x 1

2. Wall Mount Brackets x 1
* The bracket pieces are stored at the bottom of the box (beneath the foam).

3. Stylus x 1

4. Power Cable (AC 100V-240V) x 1

⚠ Do not disassemble the D7 without the supervision of a DTEN
   technician. Improper use may be subject to voiding the warranty.

What's Inside

D7 AV bar

D7 accessory bag

D7 Wall mount brackets

Quick Setup

STEP 1
Install the antennas.

PC

(Side view)

STEP 2
Plug in the power cord to the outlet.
Please Note: The power switch at
the panel's bottom should be set
to "on" by default. If the DTEN logo
does not come on, please press the
switch to the "on" setting.

(Back view)

Power switch

STEP 3
Follow the instructions on-screen
to set up the network.
Ethernet connection is preferred.

* For more info about the product, please visit dten.com

Zoom Rooms Setup

STEP 1 You need a Zoom Rooms account to sign in.

STEP 2 Select an existing room or create a new room.

* Please go to Zoom Help Center for more info

Tips

1. Increase the volume to the max using the volume button

   (the first button at the back of the unit).

2. Ethernet connection is preferred for the best meeting experience.

3. To pair with the zoom rooms controller, please visit zoom.us.

4. Please do not disconnect the power without properly shutting down the system.

5. Do not disassemble the DTEN product without the supervision of a DTEN technician.

If you have any questions, feel free to contact us.

✉ support@dten.com   ☎ +1 800 936 3836

Port Diagrams

Side

PC

Antenna
Power
USB 3.0
Ethernet LAN
Audio 3.5mm
VGA
HDMI Out
Antenna

Back

Stylus

Volume up
Volume down
Menu
Power

Short press - Trigger menu
Short press - Screen sleep
Long press - System off

RS232
(male)
VGA
(female)
SPDIF
LAN

Audio

Wall Mount

300mm

89mm

100mm

100mm

Mounting Hole Pattern: 400 x 300mm

400mm

300mm

300mm

400mm

⚠ Note: Contact a professional for assistance when wall mounting your display.
We are not responsible for any damage to the product or injury to yourself.
Do not power on the display when performing wall mount installation. It may cause personal injury due to electric shock.

DTEN

D7 75"
Product Guide

Packing List

1. DTEN D7 75" (Standard) X 1

2. Wall Mount Brackets X 1

The bracket pieces are stored at the bottom of the box (beneath the foam).

3. Stylus X 1

4. Power Cable (AC 100V-240V) X 1

⚠ Do not disassemble the D7 without the supervision of a DTEN technician. Improper use may be subject to voiding the warranty.

What's Inside

D7 AV bar

DTEN

D7 accessory bag

D7 Wall mount brackets

Quick Setup

STEP 1
Install the antennas.


PC

(Side view)

STEP 2
Plug in the power cord to the outlet. The display will turn on.

Power

STEP 3
Follow the instructions on-screen to set up the network. Ethernet connection is preferred.

For more info about the product, please visit dten.com

Zoom Rooms Setup

STEP 1 You need a Zoom Rooms account to sign in.

STEP 2 Select an existing room or create a new room.

* Please go to Zoom Help Center for more info

Tips

1. Ethernet connection is preferred for the best meeting experience.

2. To pair with the zoom rooms controller, please visit zoom.us.

3. Please do not disconnect the power without properly shutting down the system.

4. Do not disassemble the DTEN product without the supervision of a DTEN technician.

If you have any questions, feel free to contact us.

✉ SUPPORT@DTEN.COM 📞 +1.866 936.3836

Port Diagram

Side

PC

Antenna Power
USB 3.0

USB 3.0
Ethernet LAN
Audio 3.5mm
MIC

HDMI Out
Antenna

HDMI IN

Back

DTEN

Stylus

Help

Short press • Menu
Long press • System off

Menu

Wall Mount

300mm

89mm

100mm

100mm

Mounting Hole Pattern: 800mm x 400mm

DTEN

800mm

400mm

400mm

800mm

⚠ Note: Contact a professional for assistance when wall mounting your display.
We are not responsible for any damage to the product or injury to yourself.
Do not power on the display when performing wall mount installation. It may cause personal injury due to electric shock.