


Full HD 1080P Video Game Capture H.264 encoder

Model: HDVC01

Operating Instructions



Dear Customer

Thank you for purchasing this product. For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

FEATURES

- Support HDMI signal source of PlayStation 4, Xbox One and Xbox 360 game play in brilliant 1080p@60HZ with advanced H.264 encoding.
- Recording with one-click, easy to use. no need any set up just click "RECODE" button to record your game play and re-click to stop recording.
- Support NTFS/FAT32 format.
- Support USB 2.0 Host.
- Automatically split the video up to 2GB per file.
- Support record video format of MPEG-4 and audio format of RCA L/R 3.5mm microphone input.
- Support downscaling to 720P.

NOTICE

Our company reserves the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.



CUSTOMER CARE CENTRE

12 MONTH WARRANTY

1 THIS PRODUCT IS WARRANTED FOR 12 MONTHS FROM THE DATE OF PURCHASE.

Subject to the conditions of this warranty, the Customer Care Centre will perform necessary service on the product without charge for parts, or labour if, in the opinion of the manufacturer/ manufacturer's agent, the product is found to be faulty within the warranty period.

2 This warranty only applies if the product has been installed and used in accordance with the manufacturer's recommendations (as noted in the operating instructions) under normal use and reasonable care. The warranty covers normal domestic use only and does not cover damage, malfunction or failure resulting from use of incorrect voltage, accident, misuse, neglect, build-up of dirt or dust, abuse, mis-adjustment of customer controls, mains supply problems, thunderstorm activity, infestation by insects or vermin, tampering or repair by unauthorised persons (including unauthorised alterations), exposure to abnormally corrosive conditions or any foreign object or matter having entered the product.

This warranty only applies if the product has been installed and used in accordance with the manufacturer's recommendations (as noted in the operating instructions) under normal use and reasonable care. The warranty covers normal domestic use only and does not cover damage, malfunction or failure resulting from use of incorrect voltage, accident, misuse, neglect, build-up of dirt or dust, abuse, mis-adjustment of customer controls, mains supply problems, thunderstorm activity, infestation by insects or vermin, tampering or repair by unauthorised persons (including unauthorised alterations), exposure to abnormally corrosive conditions or any foreign object or matter having entered the product.

3 If warranty service is required you should:

- Telephone the Customer Care Centre on 1300 662 946
- Provide a copy of your purchase receipt that shows retailer's identity and date of purchase.
- Send or bring the product to your Customer Care Centre. Please note that freight to and/or from your Customer Care Centre must be arranged by you.

4 The warranties hereby conferred do not extend to any costs associated with the delivery, handling, freighting or transportation of the product or any part thereof or replacement of and do not extend to any damage or loss occurring during, or associated with transit.

**THIS WARRANTY CARD AND THE PURCHASE DOCKET
(OR SIMILAR PROOF OF PURCHASE)
SHOULD BE RETAINED BY THE CUSTOMER AT ALL TIMES**

**TROUBLE SHOOTING HELP LINE
1300 662 946**

Customer Care Centre
562 Spencer Street, West Melbourne
VICTORIA 3003

Pro.2
Providing AV Solutions

This advice does not limit, override or later your guaranteed rights under the Australian Consumer Law, including remedies for any failure of the Consumer Guarantees, which may include repair or replacement or it a Major Failure (as defined under the Australian Consumer Law) a replacement or refund. These guaranteed rights cannot be varied by Pro.2 or retailers of its products and have no set time limit.

TABLE OF CONTENTS

- Specifications
- Package Contents
- Panel Descriptions
- Connecting and Operating
- Maintenance
- Product Service


SPECIFICATIONS

Operating Temperature Range	-5 to +35°C(+23 to +95°F)
Operating Humidity Range	5 to 90%RH (No Condensation)
Output Video Format	MPEG-4
encoder	H.264
Input resolution	720x480(60HZ);720x576(50HZ);1280X720P(50HZ/60HZ) 1920X1080i(50HZ/60HZ); 1920X1080P(24HZ/25HZ/30HZ/50HZ/60HZ)
Capture resolution	720x480(60HZ);720x576(50HZ);1280X720P(50HZ/60HZ) 1920X1080i(50HZ/60HZ); 1920X1080P(24HZ/25HZ/30HZ)
Support Audio Format	LPCM
Bandwidth	2.25Gbps
USB	2.0
Power consumption	3watts(Maximum)
Dimension (LxWxH)	102.2x70.1x27.1mm
Net Weight	220g(Pcs)

PACKING CONTENTS

- 1) Game capture
- 2) 5V/1A x1 PCS
- 3) Operating Instructions

PANEL DESCRIPTIONS



1. 3.5mm microphone input socket
2. 1080P by pass or downscale to 720P (resolution lower than 720P, switch to "720P" position, it is by pass mode)
3. "RECORD" button (click "RECORD" button to record your game play and re-click to stop recording)
4. USB port
5. HDMI output
6. HDMI input
7. Power input

CONNECTING AND OPERATING

- 1) Connect the HDMI signal sources (Such as Industry HD Camera, PlayStation 4, and Xbox 360 etc).
 - 2) Connect the HDMI Output (Such as Computer, TV).
 - 3) Connect the USB host (Such as HDD or USB flash).
 - 4) Connect the microphone to the "Mic" hole.
 - 5) Connect the DC 5V1A power supply.
 - 6) Power on and click the "RECODE" button to start recording.
 - 7) The LED status will flash when start recording.
 - 8) Re-click the "RECODE" button to stop recording.
 - 9) The LED status will stop flashing and keep lighting when finishing recording.
- Attention: Insert/Extract cables gently.

MAINTENANCE

Clean this unit with a soft, dry cloth. Never use alcohol, paint thinner or benzine to clean this unit.

PRODUCT SERVICE

- 1) **Damage requiring service:**
The unit should be serviced by qualified service personnel if:
 - (a) The DC power supply cord or AC adaptor has been damaged;
 - (b) Objects or liquids have gotten into the unit;
 - (c) The unit has been exposed to rain;
 - (d) The unit does not operate normally or exhibits a marked change in performance;
 - (e) The unit has been dropped or the cabinet damaged.
- 2) **Servicing Personnel:** Do not attempt to service the unit beyond that described in these operating instructions. Refer all other servicing to authorized servicing personnel.
- 3) **Replacement parts:** When parts need replacing ensure the servicer uses parts specified by the manufacturer or parts that have the same characteristics as the original parts. Unauthorized substitutes may result in fire, electric shock, or other hazards.